


INSTALLATION BY QUALIFIED/EXPERIENCED TECHNICIANS ONLY

AFTER COMPLETING INSTALLATION, FIX THESE INSTRUCTIONS ADJACENT TO THE BOSS[™] D-POT[®] TO BE CLEARLY VISIBLE.





6)Open Valve (2) slightly to let the water into the vessel, make sure all the air is vented through the Air Vent (B), then close and plug Valve (5) and open Valves (2) and (1) completely.

7)The system water will now flow through and dose the chemicals into the system as a whole.

BOSS D-POT[®]

é

WE ADVISE DOSING WITH THE FOLLOWING QUALITY TESTED INHIBITOR:

DRAIN

